

ZONES

Phoenix Bell, Paging & Intercom

DOCUMENT PURPOSE

The purpose of this document is to instruct the Phoenix Bell, Paging & Intercom user how to use existing Zones as well as create new Zones.

Note: These instructions apply to Standard, Admin and Master Admin users.

This document assumes the reader has the appropriate user credentials, (user name and password), as well as the IP address or DNS name of the Phoenix Bell, Paging & Intercom system.

CONTENTS

Document Purpose	1
General Zones Overview	1
Getting Started	2
Instructions	2
Show Devices in a Zone	
Adding a Device to a Zone	3
Deleting A Device From a Zone	5
•	
Creating a Zone	ხ

GENERAL ZONES OVERVIEW

Zones provide two basic, yet very powerful functions, in the Phoenix Bell, Paging and Intercom system and these two functions are interrelated.

The first function of the Zone is to provide a bell sound to the group of devices which make up the Zone. The second function is to provide a group of devices to receive a Paging audio. Simply stated, a Zone may receive bell sounds and Paging audio.

PBPI comes with three built in Zones:

- All Call Ext. 6060 This Zone will normally contain all devices in the building.
 - Note: In some cases, (per request of the building) the "Admin Area" device may be removed from the
 Zone.
- All Interior Ext. 6061 This Zone will normally contain only Interior devices.
- All Exterior Ext. 6062 This Zone will normally contain only exterior devices.
- Other Zones may be created based on the needs of the building.



All Zones have an Intercom Extension associated with the Zone allowing each Zone to receive Paging audio from the Intercom, (BAT), phone or the building phone when integrated with PBPI system.

The install team will generally add all the devices in the building to the All Call Zone as well as the All Interior and All Exterior Zones.

GETTING STARTED


Getting started with Zones is typically quite simple. The user will need to know if they are going to View what devices are a member of the Zone, edit which devices are part of the Zone, Create a Zone or Delete a Zone.

Note: If the user will be adding a Zone to the PBPI, the user must plan on an Intercom Extension for the new Zone.


INSTRUCTIONS

SHOW DEVICES IN A ZONE

- 1. Log into PBPI
- 2. Click Zones in the menu
- 3. Click Manager




4. Click the Show Devices button






- The screen will display which devices are a member of the Zone
- 6. To Edit the Zone, see "Adding a Device to a Zone" or "Deleting a Device From a Zone"




ADDING A DEVICE TO A ZONE

- 1. Log into PBPI
- 2. Click **Zones** in the menu
- 3. Click Manager




- 4. Click the **Action** button
- 5. Click Assign Devices







- 6. Select, (shift click for multiple devices), the device(s) to be added to the Zone
- 7. Click the **Double Right** arrow in the center of the screen



- 8. Image shown right shows two devices added to the Zone
- 9. Click the **Submit** button



10. Click the **Apply** button to complete the process







DELETING A DEVICE FROM A ZONE


- 1. Log into PBPI
- 2. Click **Zones** in the menu
- 3. Click Manager

- 4. Click the **Action** button
- 5. Click Assign Devices

- 6. Click, (shift click for multiple devices), the device to be added to the Zone
- 7. Click the **Double Left** arrow in the center of the screen











- 8. Image shown right shows one device removed from the Zone
- 9. Click the **Submit** button




10. Click the **Apply** button to complete the process




CREATING A ZONE

- 1. Log into PBPI
- 2. Click **Zones** in the menu
- 3. Click Manager






4. Click the Add Zones button



- 5. Type the name of the Zone in the **Name** field
- 6. (Optional) drag the slider to choose a color for the Zone or type the HEX number in the field
- 7. Type the Zone Extension in the **Extension** field Note: Zone Extensions must start with the number 6.
- 8. Click the **Submit** button



- 9. Click the **Apply** button to complete the process
- 10. Add devices to the Zone (See Adding a Device to a Zone)

